



Eddie Bauer® Ladies Hooded Soft Shell Parka

SIZE CHART

	XS	S	M	L	XL	2XL	3XL	4XL
Size	2	4/6	8/10	12/14	16/18	20/22	24/26	28/30
Bust	32-33	34-35	36-37	38-40	41-43	44-46	47-49	50-52

BUST

With arms down at sides, measure around the upper body, under arms and around the fullest part of the bust.